

ROUTE 145, WINTHROP ROAD
 CHESTER, CONNECTICUT 06412-0684
 TELEPHONE: (860) 526-9504
 FAX: (860) 526-4078

Installation Procedure:

1. Locate and remove the screws that secure the existing headlight bezel cover to the vehicle. Remove this bezel, then unplug and remove the headlight.
2. Unhook the retaining spring and remove the existing light housing from the vehicle.
3. Insert the grommets into the mounting bracket as shown in the illustration. (See warning below)
4. Attach the lighthood to the bracket using the supplied screws as shown.
5. Thread the wire harness through the existing wire hole, (If no hole exists, drill a hole through the main housing and install an appropriately sized grommet) and secure the bracket to the housing using the supplied screws.

NOTE: Be sure to use the correct spacers depending upon whether your application is ATI or KD. Both types of spacers are included. (See Illustration)

6. Plug the light into the harness.
7. Secure the lighthood to the new bracket with the 4 lens screws. They will thread into the fastex grommets in the bracket and hold the lighthood on.
8. Replace the bezel cover and secure it with the 4 retaining screws which will thread into the remaining fastex grommets in the bracket.

QTY.	ITEM	PART NUMBER	DESCRIPTION
-	-	01-0682906-00	6E HEADLIGHT REPLACEMENT KIT
4	2	13-062C40-16J	#6 FASTEX SCREW GROMMET
1	3	07-283568-023	HEADLIGHT RETAINER BRACKET
2	4	20-0021625-00	SPACER
2	5	20-0416129300	.125" SPACER
4	6	21-1706081873	#6 FASTEX SCREW GROMMET

